

ALTO SHAAM® HALO® HEAT®



EC2SYS Systems shown
with optional black
formica half end panels
and stainless steel skirt.

EC2SYS-48



EC2SYS-72



EC2SYS-96

INSTALLATION OPERATION AND MAINTENANCE MANUAL

HEATED DISPLAY CASES

*FULL SERVICE OR
SELF SERVICE
EUROPEAN STYLE*

SERIES:

EC2-48
EC2SYS-48

EC2-72
EC2SYS-72

EC2-96
EC2SYS-96

W164 N9221 Water Street • P.O. Box 450 • Menomonee Falls, Wisconsin 53052-0450 USA

PHONE: 262.251.3800

800.558-8744 USA/CANADA

FAX: 262.251.7067 • 800.329.8744 U.S.A. ONLY

262.251.1907 INTERNATIONAL

WEBSITE:


www.alto-shaam.com

ALTO-SHAAM® HEATED DISPLAY CASES

UNPACKING & SET-UP

The Alto-Shaam Heated Display Case has been thoroughly tested, checked for calibration, and inspected to insure only the highest quality unit is provided. When you receive your case, check for any possible shipping damage and report it at once to the delivering carrier.

See *Transportation Damage and Claims* section located in this manual.




In order to maintain established National Sanitation Foundation standards, all stationary floor models must be sealed to the floor with a R.T.V. or silastic meeting N.S.F. requirements or have 6" (153mm) unobstructed clearance beneath the unit.

Counter and table units must be mounted on legs of a sufficient 4" (102mm) height to provide minimum unobstructed space beneath the unit. These legs are supplied with the unit. Warranty will become null and void if these directions are not followed.

Save all the information and instructions packed inside the display case. Complete and return the warranty card to the factory as soon as possible to assure prompt service in the event of a warranty parts and labor claim.


NOTE: Any and all claims for warranty must include the full model and serial number of the display case.



ELECTRICAL INSTALLATION

If necessary, permanent wiring or electrical outlets for this display case must be installed by an licensed electrician in accordance with local, country or national codes.

SAMPLE



An identification tag is permanently mounted on case. Plug the case into a properly grounded receptacle **ONLY**. Arcing will occur when connecting or disconnecting the display case unless all controls are in the OFF position. Always position the appliance so the power supply cord is easily accessible in case of emergency.

REGARDING INTERNATIONAL STANDARD UNITS:






If the unit is not equipped with flexible cord with plug, an all-pole country approved disconnection device which has a contact separation of at least 3mm in all poles must be incorporated in the fixed wiring for disconnection. When using a cord without a plug, the green/yellow conductor shall be connected to the terminal which is marked with the ground symbol. If a plug is used, the socket outlet must be easily accessible. If the power cord needs replacement, use a similar one obtained from the distributor.

For 230V units: To prevent an electrical shock hazard between the appliance and other appliances or metal parts in close vicinity, an equalization-bonding stud is provided. An equalization bonding lead must be connected to this stud and the other appliances / metal parts to provide sufficient protection against potential difference. The terminal is marked with the following symbol.



INSTALLATION

OUTSIDE DIMENSIONS



INSTALLATION

EC2 SERIES — OPTIONS & ACCESSORIES

DESCRIPTION	EC2-48 SERIES	EC2-72 SERIES	EC2-96 SERIES
END PANELS, FULL, MIRRORED MIRRORED OUTSIDE, MIRRORED INSIDE	PE-26646	PE-26646	PE-26646
END PANELS, FULL, STAINLESS STEEL/MIRRORED LEFT-SIDE STAINLESS STEEL OUTSIDE, MIRRORED INSIDE RIGHT-SIDE	PE-26693 PE-26694	PE-26693 PE-26694	PE-26693 PE-26694
END PANELS, FULL, FORMICA/MIRRORED LEFT-SIDE BLACK FORMICA OUTSIDE, MIRRORED INSIDE RIGHT-SIDE	PE-26701 PE-26700	PE-26701 PE-26700	PE-26701 PE-26700
END PANELS, HALF, BLACK FORMICA	PE-24749	PE-24749	PE-24749
ELECTRICAL OUTLET ONE PER UNIT, RIGHT SIDE, OPERATOR VIEW	<i>contact factory</i>	<i>contact factory</i>	<i>contact factory</i>
FRONT PANEL, BASE CUSTOM COLOR BRUSHED STAINLESS STEEL WHITE	<i>contact factory</i> <i>contact factory</i> <i>contact factory</i>	<i>contact factory</i> <i>contact factory</i> <i>contact factory</i>	<i>contact factory</i> <i>contact factory</i> <i>contact factory</i>
FRONT PANEL, TOP CUSTOM COLOR STAINLESS STEEL	<i>contact factory</i> <i>contact factory</i>	<i>contact factory</i> <i>contact factory</i>	<i>contact factory</i> <i>contact factory</i>
GAUGE, INTERIOR AMBIENT TEMPERATURE	GU-33384	GU-33384	GU-33384
GLASS DIVIDER FOR BUTTING MULTIPLE CASES	<i>contact factory</i>	<i>contact factory</i>	<i>contact factory</i>
GLASS, NON-GLARE, FRONT	GL-24256	GL-26695	GL-24256 2 REQUIRED
GLASS, TEMPERED END PANE RIGHT-HAND — BRONZE REFLECTIVE LEFT-HAND	GL-24166 GL-24167	GL-24166 GL-24167	GL-24166 GL-24167
PAN, 4" (102mm) DEEP SELF-SERVICE	1001990	1001991	—
PLATFORM, SCALE CUSTOMER VIEW RIGHT-HAND OR LEFT-HAND	55265	55265	55265
SHEET PAN, DIVIDER BAR PACKAGE EC2-48 SERIES EC2-72 SERIES EC2-96 SERIES	5002802 — —	— 5002803 —	— — 5002805

OPERATING PROCEDURES

1. DO NOT ADD WATER TO DISPLAY CASE

Halo Heat display cases maintain a constant but gentle temperature and eliminate much of the moisture loss associated with conventional display cases. Because of this gentle heat, it is not necessary to add water to the display case. As a matter of fact, **adding water is not recommended** since water will accelerate the deterioration of the product, and may damage the unit voiding the warranty.

2. PLACE DIVIDERS AND SERVING PANS IN CASE

Refer to the pan layout diagrams for different types of pan accommodations. A complete pan configuration layout is located in this manual. **It is VERY important to note**, no matter what type of pan configuration chosen, pan separator bars or divider bars must be used to close all gaps between pans, and all gaps between the pans and the edges of the display case. If these gaps are not closed, heat will escape from the bottom of the case into the display area. As a consequence, heat distribution will be uneven and uniform temperature will be difficult to hold. If needed, additional pan divider bars are available. The supplied self-serve pan inserts with wire grids are for use with pre-packaged foods in the self-serve sections of the units.

3. TURN DISPLAY LIGHTS "ON" AND SET THE THERMOSTAT(S) AT NUMBER "10" TO PREHEAT

A indicator light will illuminate when the thermostat(s) is (are) turned "ON." The indicator(s) will remain lit as long as the unit is preheating or calling for heat. The unit should be preheated at the **10** setting for a minimum of 30-45 minutes before loading the case with hot food. When preheating is completed, or whenever the unit reaches any temperature set by the operator between **1** and **10**, the indicator light(s) will go "OUT".

4. LOAD HOT FOODS INTO DISPLAY CASE

Be certain only hot food is transferred into the display case. Before loading food into the case, use a pocket-type meat thermometer to make certain all products have reached an internal temperature of 140° to 160° F (60° to 71°C). If any food product is not at proper serving temperature, use a Halo Heat cooking and holding oven, set at 250° to 275°F (121° to 135°C), or a Combitherm oven to bring the product within the correct temperature range.

- Use hand protection when handling hot items.
- Be certain only hot PREPACKAGED foods in appropriate heat tested containers are used in the self-service section of the display case.
- Do not stack food containers.

5. RESET THERMOSTAT(S) AS NEEDED

After all products are loaded into the display case and the doors are closed, it is necessary to reset the thermostat(s). For fully enclosed sections, reset the thermostat to the number "8" setting. Cases with a self-service section should be maintained between number "9" and number "10" for the self-service section **only**. THESE SETTINGS WILL NOT NECESSARILY BE FINAL. Since proper temperature range depends on the type of products and the quantities being held, it is necessary to periodically use a pocket thermometer to check each item to make certain the correct temperatures are being maintained. Proper temperature range is between a minimum of 140° and 160° F (60° and 71° C). Normally, this will require a thermostat setting of between number "6" and "8" in fully enclosed cases. Self-service cases or sections will always require a higher thermostat setting.

6. PLACEMENT OF FOOD PROBE


If the unit is equipped with the probe accessory, wipe each probe and probe tip with a disposable alcohol pad to clean and sanitize before using. If the probe is left in its bracket, the LED temperature display will indicate the ambient air temperature inside the case. To place a probe into food kept in the case, remove the probe from the bracket and push the probe tip halfway into the product, positioning the tip at the center of the food mass. If placing into solid foods such as meat roast or poultry breasts, push the probe in from a straight downward position or in from the side to the center position. If placing into a semi-liquid or liquid product, the probe cable will probably need to be secured to keep the probe positioned properly. Do not let the probe tip touch the edges or sides. Tape the probe cable to the lip or edge of the container. Wipe each probe tip with a clean paper towel to remove food debris after each use. Follow by wiping probes with a disposable alcohol pad, and return each probe to the proper bracket position.

7. SERVE FRESH HOT FOOD


Keep hot foods looking fresh. Occasionally stir or rotate food as needed. Serve food products in appropriate heat tested packages or containers. Keep display case doors closed after serving. Wipe spills immediately to assure maximum eye appeal and to ease end of the day cleanup.

OPERATION

EC2 Series Controls




Operator/Control side with cutting board



OPERATION


PAN CONFIGURATIONS • HEATED DISPLAY CASES




STANDARD PAN DIVIDER and SEPARATOR BARS

NO.	DESCRIPTION	DIMENSIONS	MODELS		
			48	72	96
11047	ONE-THIRD SIZE PAN	3-1/4" x 7" (83mm x 178mm)	1	—	—
1002584	FULL, HALF AND THIRD SIZE-LONG	3-11/16" x 28" (93mm x 711mm)	4	4	—
1002590	FULL, HALF AND THIRD SIZE-LONG	3" x 28" (76mm x 711mm)	—	—	6
11318	FULL, HALF AND THIRD SIZE-SHORT	1" x 12-3/4" (25mm x 324mm)	9	15	21
1002621	FULL, HALF AND THIRD SIZE-SHORT	2-7/16" x 12-3/4" (62mm x 324mm)	3	5	7

OPERATION



Part No.	International pan divider and separator bars		Models		
			48	72	96
1002585	GN 1/1, GN 1/2, GN 1/3 - Long	58 mm x 711 mm	4	4	-
1002591	GN 1/1, GN 1/2, GN 1/3 - Long	41 mm x 711 mm	-	-	6
1002619	GN 1/4	25 mm x 270 mm	6	10	14
1000544	GN 1/1, GN 1/2, GN 1/3 - Short	25 mm x 327 mm	9	15	21



OPERATION

GENERAL HOLDING GUIDELINES

Chefs, cooks and other specialized food service personnel employ varied methods of cooking. Proper holding temperatures for a specific food product must be based on the moisture content of the product, product density, volume, and proper serving temperatures. Safe holding temperatures must also be correlated with palatability in determining the length of holding time for a specific product.

Halo Heat maintains the maximum amount of product moisture content without the addition of water, water vapor, or steam. Maintaining maximum natural product moisture preserves the natural flavor of the product and provides a more genuine taste. In addition to product moisture retention, the gentle properties of Halo Heat maintain a consistent temperature throughout the cabinet without the necessity of a heat distribution fan, thereby preventing further moisture loss due to evaporation or dehydration.

In an enclosed holding environment, too much moisture content is a condition which can be relieved. A product achieving extremely high temperatures in preparation must be allowed to decrease in temperature before being placed in a controlled holding atmosphere. If the product is not allowed to decrease in temperature, excessive condensation will form increasing the moisture content on the outside of the product.

Most Halo Heat Holding Equipment is provided with a thermostat control between 60° and 200°F (16° to 93°C). If the unit is equipped with vents, close the vents for moist holding and open the vents for crisp holding.

If the unit is equipped with a thermostat indicating a range of between 1 and 10, use a metal-stemmed indicating thermometer to measure the internal temperature of the product(s) being held. Adjust the thermostat setting to achieve the best overall setting based on internal product temperature.

HOLDING TEMPERATURE RANGE

MEAT	FAHRENHEIT	CELSIUS
BEEF ROAST — Rare	140°F	60°C
BEEF ROAST — Med/Well Done	160°F	71°C
BEEF BRISKET	160° — 175°F	71° — 79°C
CORN BEEF	160° — 175°F	71° — 79°C
PASTRAMI	160° — 175°F	71° — 79°C
PRIME RIB — Rare	140°F	60°C
STEAKS — Broiled/Fried	140° — 160°F	60° — 71°C
RIBS — Beef or Pork	160°F	71°C
VEAL	160° — 175°F	71° — 79°C
HAM	160° — 175°F	71° — 79°C
PORK	160° — 175°F	71° — 79°C
LAMB	160° — 175°F	71° — 79°C
POULTRY		
CHICKEN — Fried/Baked	160° — 175°F	71° — 79°C
DUCK	160° — 175°F	71° — 79°C
TURKEY	160° — 175°F	71° — 79°C
GENERAL	160° — 175°F	71° — 79°C
FISH/SEAFOOD		
FISH — Baked/Fried	160° — 175°F	71° — 79°C
LOBSTER	160° — 175°F	71° — 79°C
SHRIMP — Fried	160° — 175°F	71° — 79°C
BAKED GOODS		
BREADS/ROLLS	120° — 140°F	49° — 60°C
MISCELLANEOUS		
CASSEROLES	160° — 175°F	71° — 79°C
DOUGH — Proofing	80° — 100°F	27° — 38°C
EGGS — Fried	150° — 160°F	66° — 71°C
FROZEN ENTREES	160° — 175°F	71° — 79°C
HORS D'OEUVRES	160° — 180°F	71° — 82°C
PASTA	160° — 180°F	71° — 82°C
PIZZA	160° — 180°F	71° — 82°C
POTATOES	180°F	82°C
PLATED MEALS	180°F	82°C
SAUCES	140° — 200°F	60° — 93°C
SOUP	140° — 200°F	60° — 93°C
VEGETABLES	160° — 175°F	71° — 79°C

THE HOLDING TEMPERATURES LISTED ARE SUGGESTED GUIDELINES.

CARE AND CLEANING

The cleanliness and appearance of this equipment will contribute considerably to operating efficiency and savory, appetizing food. Good equipment that is kept clean works better and lasts longer.



1. CLEAN THE PROBES DAILY

If the display case is supplied with probes, remove all food soil from probes. Wipe entire probe and cable assembly with warm detergent solution and a clean cloth. Remove detergent by wiping each probe and cable with clean rinse water and a cloth. Wipe probes with disposable alcohol pad or sanitizing solution recommended for food contact surfaces. Allow probe and cable to air dry in probe holding bracket.



2. THOROUGHLY CLEAN THE UNIT DAILY

- A. Turn lights and adjustable thermostat(s) to the "OFF" position, and disconnect unit from power source.
- B. Remove, cover or wrap, and store unused products under refrigeration.
- C. Clean the interior metal surfaces of the cabinet with a damp clean cloth and any good commercial detergent or grease solvent at the recommended strength. Use a plastic scouring pad or oven cleaner for difficult areas. Rinse by wiping with a sponge and clean warm water to remove all residue. Remove excess water with sponge and wipe dry with a clean cloth or air dry.



THIS UNITS PERFORMANCE HAS BEEN OPTIMIZED USING THE FACTORY PROVIDED BULBS. THESE BULBS SHOULD BE REPLACED WITH AN EXACT REPLACEMENT OR WITH A FACTORY RECOMMENDED REPLACEMENT. THESE BULBS HAVE BEEN TREATED TO RESIST BREAKAGE AND MUST BE REPLACED WITH SIMILARLY TREATED BULBS IN ORDER TO MAINTAIN COMPLIANCE WITH NSF STANDARDS. DO NOT OVER-TIGHTEN BULBS IN THEIR RECEPTACLES AS THIS CAN CAUSE DAMAGE TO THE BULB FILAMENT.

NOTE: Avoid the use of abrasive cleaning compounds, chloride based cleaners, or cleaners containing quaternary salts. Never use hydrochloric acid (muriatic acid) on stainless steel.

- D. Clean the glass with a window cleaner. The sliding glass doors are removable allowing for easier cleaning.
- E. To help maintain the protective film coating on polished stainless steel, clean the exterior of the unit with a cleaner recommended for stainless steel surfaces. Spray the cleaning agent on a clean cloth and wipe with the grain of the stainless steel.

Always follow appropriate state or local health (hygiene) regulations regarding all applicable cleaning and sanitation requirements for equipment.

DO NOT USE IF CONTROLS ARE NOT PROPERLY FUNCTIONING

Refer to the Trouble Shooting Guide located in this manual or call an authorized service technician.

CHECK OVERALL CONDITION ONCE A MONTH

Check the case and related cabinets once a month for physical damage and loose screws. Correct any problems before they begin to interfere with the operation of the unit.



AT NO TIME SHOULD THE INTERIOR OR EXTERIOR BE STEAM CLEANED, HOSED DOWN, OR FLOODED WITH WATER OR LIQUID SOLUTION. DO NOT USE WATER JET TO CLEAN. SEVERE DAMAGE OR ELECTRICAL HAZARD COULD RESULT. WARRANTY BECOMES VOID IF APPLIANCE IS FLOODED.



HOOD GLASS EXTENDED TO THE FULL UPRIGHT POSITION IS STABILIZED THROUGH THE USE OF GAS STRUTS DESIGNED FOR THE FULL LOAD BEARING WEIGHT. THESE STRUTS COULD WEAKEN OR FAIL DUE TO WEAR, ENVIRONMENTAL CONDITIONS OR AGING.

OPERATORS SHOULD BE AWARE OF ANY DECREASE IN EFFORT TO LIFT THE HOOD AND INITIATE AN IMMEDIATE GAS STRUT SAFETY CHECK.

DO NOT LIFT THE HOOD IN THIS CONDITION.

SANITATION

SANITATION GUIDELINES

Food flavor and aroma are usually so closely related that it is difficult, if not impossible, to separate them. There is also an important, inseparable relationship between cleanliness and food flavor. Cleanliness, top operating efficiency, and appearance of equipment contribute considerably to savory, appetizing foods. Good equipment that is kept clean, works better and lasts longer.

Most food imparts its own particular aroma and many foods also absorb existing odors. Unfortunately, during this absorption, there is no distinction between *GOOD* and *BAD* odors. The majority of objectionable flavors and odors troubling food service operations are caused by bacteria growth. Sourness, rancidity, mustiness, stale or other *OFF* flavors are usually the result of germ activity.

The easiest way to insure full, natural food flavor is through comprehensive cleanliness. This means good control of both visible soil (dirt) and invisible soil (germs). A thorough approach to sanitation will provide essential cleanliness. It will assure an attractive appearance of equipment, along with maximum efficiency and utility. More importantly, a good sanitation program provides one of the key elements in the prevention of food-borne illnesses.

A controlled holding environment for prepared foods is just one of the important factors involved in the prevention of food-borne illnesses. Temperature monitoring and control during receiving, storage, preparation, and the service of foods are of equal importance.

The most accurate method of measuring safe temperatures of both hot and cold foods is by internal product temperature. A quality thermometer is an effective tool for this purpose, and should be routinely used on all products that require holding at a specific temperature.

A comprehensive sanitation program should focus on the training of staff in basic sanitation procedures. This includes personal hygiene, proper handling of raw foods, cooking to a safe internal product temperature, and the routine monitoring of internal temperatures from receiving through service.

Most food-borne illnesses can be prevented through proper temperature control and a comprehensive program of sanitation. Both these factors are important to build quality service as the foundation of customer satisfaction. Safe food handling practices to prevent food-borne illness is of critical importance to the health and safety of your customers.





HACCP, an acronym for Hazard Analysis (at) Critical Control Points, is a quality control program of operating procedures to assure food integrity, quality, and safety. Taking steps necessary to augment food safety practices are both cost effective and relatively simple. While HACCP guidelines go far beyond the scope of this manual, additional information is available by contacting:

Center for Food Safety and Applied Nutrition
Food and Drug Administration
1-888-SAFEFOOD

INTERNAL FOOD PRODUCT TEMPERATURES		
HOT FOODS		
DANGER ZONE	40° TO 140°F	(4° TO 60°C)
CRITICAL ZONE	70° TO 120°F	(21° TO 49°C)
SAFE ZONE	140° TO 165°F	(60° TO 74°C)
COLD FOODS		
DANGER ZONE	ABOVE 40°F	(ABOVE 4°C)
SAFE ZONE	36°F TO 40°F	(2°C TO 4°C)
FROZEN FOODS		
DANGER ZONE	ABOVE 32°F	(ABOVE 0°C)
CRITICAL ZONE	0° TO 32°F	(-18° TO 0°C)
SAFE ZONE	0°F OR BELOW	(-18°C OR BELOW)

SERVICE

EC2 Series - Service Views



SERVICE

Cable Replacement Kits

EC2-48 Series Cable Replacement Kit

Cable Heating Service Kit No. 4880

includes:

CB-3045	Cable Heating Element	134 feet
CR-3226	Ring Connector	4
IN-3488	Insulation Corner	1 foot
BU-3105	Shoulder Bushing	4
BU-3106	Cup Bushing	4
SL-3063	Insulating Sleeve	4
TA-3540	High Temperature Tape	1 roll
ST-2439	Stud, 10/32	4
NU-2215	Hex Nut	8

EC2-72 Series Cable Replacement Kit

Cable Heating Service Kit No. 4881

includes:

CB-3045	Cable Heating Element	210 feet
CR-3226	Ring Connector	12
IN-3488	Insulation Corner	1 foot
BU-3105	Shoulder Bushing	12
BU-3106	Cup Bushing	12
SL-3063	Insulating Sleeve	12
TA-3540	High Temperature Tape	1 roll
ST-2439	Stud, 10/32	12
NU-2215	Hex Nut	24

EC2-96 Series Cable Replacement Kit

Cable Heating Service Kit No. 14228

includes:

CB-3045	Cable Heating Element	280 feet
CR-3226	Ring Connector	8
IN-3488	Insulation Corner	1 foot
BU-3105	Shoulder Bushing	8
BU-3106	Cup Bushing	8
SL-3063	Insulating Sleeve	8
TA-3540	High Temperature Tape	1 roll
ST-2439	Stud, 10/32	8
NU-2215	Hex Nut	16



THIS UNITS PERFORMANCE HAS BEEN OPTIMIZED USING THE FACTORY PROVIDED BULBS. THESE BULBS SHOULD BE REPLACED WITH AN EXACT REPLACEMENT OR WITH A FACTORY RECOMMENDED REPLACEMENT. THESE BULBS HAVE BEEN TREATED TO RESIST BREAKAGE AND MUST BE REPLACED WITH SIMILARLY TREATED BULBS IN ORDER TO MAINTAIN COMPLIANCE WITH NSF STANDARDS. DO NOT OVER-TIGHTEN BULBS IN THEIR RECEPTACLES AS THIS CAN CAUSE DAMAGE TO THE BULB FILAMENT.



DISCONNECT UNIT FROM POWER SOURCE BEFORE CLEANING OR SERVICING.

EC2-48 Series

Part Description	Alto-Shaam Part No.	EC2-48	
		EC2SYS-48	
1. BULBS	LP-33592	6	6
BULBS, 230V	LP-3384	6	6
RECEPTACLE, BULB	RP-3952	6	6
RECEPTACLE, BULB, 230V	RP-3955	6	6
2. BUMPER	BM-24082	1	1
BUMPER END CAP	BM-24083	2	2
BUMPER TRACK	11088	1	1
3. CLAMP, GLASS	CM-24682	1	1
4. CONTROL PANEL	1000623	1	1
5. CORD	CD-3291	1	1
CORD, 230V	CD-33490	1	1
6. CUTTING BOARD ASSEMBLY	4016	1	1
CUTTING BOARD BRACKET	BT-2342	2	2
CUTTING BOARD BRACKET BASE	11283	2	2
7. DOOR, GLASS, LEFT-HAND	DR-25422	1	1
DOOR, GLASS, RIGHT-HAND	DR-25423	1	1
8. END PANEL, LEFT-HAND	1004292	1	1
END PANEL, RIGHT-HAND	1004293	1	1
9. EQUIPOTENTIAL STUD (230V ONLY)	ST-24173	1	1
10. FUSE HOLDER	FU-3772	1	1
FUSE, 15 AMP	FU-3775	2	2
11. GLASS, END	GL-25963	2	2
GASKET, END GLASS	GS-22547	2	2
12. GLASS, FRONT	GL-24165	1	1
HANDLE, GLASS	HD-24688	1	1
13. HEATING CABLE, 132' (40234mm)	CB-3045	X	X
14. HINGE ASSEMBLY, LEFT-HAND	HG-26523	1	1
HINGE ASSEMBLY, RIGHT-HAND	HG-26522	1	1
15. INDICATOR LIGHT, WHITE	LI-3027	2	2
INDICATOR LIGHT, 230V, WHITE	LI-3951	2	2
16. INSULATION	IN-22364	3	3
INSULATION	IN-2203	1	1
17. LEGS, 6" (152mm)	LG-22341	4	-
18. PAN DIVIDERS, SEE PAGES 6 & 7			
19. PANEL, FRONT, UPPER	1004272	1	1
PANEL, FRONT, LOWER	1004275	1	1
20. PLUG	PG-3267	1	1
21. SWITCH, TOGGLE	SW-33896	2	2
22. TERMINAL BLOCK, MODULAR	BK-25432	1	1
23. THERMOSTAT	TT-3498	2	2
THERMOSTAT KNOB	KN-3473	2	2
THERMOSTAT, BEZEL	TT-3713	2	2
24. TRACK, DOOR, BOTTOM	TK-25418	1	1
TRACK, DOOR, TOP	TK-25417	1	1
25. STRUTS, GAS	SU-24829	2	2


EC2-72 Series

Part Description	Alto-Shaam Part No.	EC2-72	EC2SYS-72
1. BULBS	LP-33592	10	10
BULBS, 230V	LP-3384	10	10
RECEPTACLE, BULB	RP-3952	10	10
RECEPTACLE, BULB, 230V	RP-3955	10	10
2. BUMPER	BM-24082	1	1
BUMPER END CAP	BM-24083	2	2
BUMPER TRACK	11089	1	1
3. CLAMP, GLASS	CM-24686	1	1
4. CONTROL PANEL	1001252	1	1
5. CORD	CD-3291	1	1
CORD, 230V	CD-33490	1	1
6. CUTTING BOARD ASSEMBLY, 6' (1829mm)	4017	1	1
CUTTING BOARD BRACKET	BT-2342	2	2
CUTTING BOARD BRACKET BASE	11283	2	2
7. DOOR, GLASS, LEFT HAND	DR-25422	1	1
DOOR, GLASS, MIDDLE	DR-25423	1	1
DOOR, GLASS, RIGHT HAND	DR-25424	1	1
8. END PANEL, LEFT-HAND	1004292	1	1
END PANEL, RIGHT-HAND	1004293	1	1
9. EQUIPOTENTIAL STUD (230V ONLY)	ST-24173	1	1
10. FUSE HOLDER, 15 AMP	FU-3772	1	1
FUSE, 15 AMP	FU-3775	2	2
11. GLASS, END	GL-25963	2	2
GASKET, END GLASS	GS-22547	2	2
12. GLASS, FRONT	GL-24612	1	1
HANDLE, GLASS, EXTRUSION	HD-24689	1	1
13. HEATING CABLE, 210' (64008mm)	CB-3045	X	X
14. HINGE ASSEMBLY, LEFT-HAND	HG-26522	1	1
HINGE ASSEMBLY, RIGHT-HAND	HG-26523	1	1
15. INDICATOR LIGHT, WHITE	LI-3027	2	2
INDICATOR LIGHT, 230V, WHITE	LI-3951	2	2
16. INSULATION	IN-22364	1	1
INSULATION	IN-2203	1	1
17. LEGS, 6" (152mm)	LG-22341	4	-
18. PAN DIVIDERS, SEE PAGES 6 & 7			
19. PANEL, FRONT, UPPER	1004273	1	1
PANEL, FRONT, LOWER	1004276	1	1
20. PLUG	PG-3267	1	1
21. SWITCH, TOGGLE	SW-33896	2	2
22. TERMINAL BLOCK, MODULAR	BK-25432	1	1
23. THERMOSTAT	TT-3498	2	2
THERMOSTAT KNOB	KN-3473	2	2
THERMOSTAT, BEZEL	TT-3713	2	2
24. TRACK, DOOR, BOTTOM	TK-25792	1	1
TRACK, DOOR, TOP	TK-25569	1	1
25. STRUTS, GAS	SU-24830	2	2

EC2-96 Series


Part Description	Alto-Shaam Part No.	EC2-96	
		EC2-96	EC2SYS-96
1. BULBS	LP-33592	14	14
BULBS, 230V	LP-3384	14	14
RECEPTACLE, BULB	RP-3952	14	14
RECEPTACLE, BULB, 230V	RP-3955	14	14
2. BUMPER	BM-24082	1	1
BUMPER END CAP	BM-24083	2	2
BUMPER TRACK	11090	1	1
3. CLAMP, GLASS	CM-26588	1	1
4. CONTROL PANEL	1001467	1	1
5. CORD	CD-3291	1	1
CORD, 230V	CD-33490	1	1
6. CUTTING BOARD ASSEMBLY, 4' (1219mm)	4016	2	2
CUTTING BOARD BRACKET	BT-2342	4	4
CUTTING BOARD BRACKET BASE	11283	4	4
7. DOOR, GLASS, LEFT HAND	DR-25422	1	1
DOOR, GLASS, MIDDLE	DR-25423	2	2
DOOR, GLASS, RIGHT HAND	DR-25424	1	1
8. END PANEL, LEFT-HAND	1004292	1	1
END PANEL, RIGHT-HAND	1004293	1	1
9. EQUIPOTENTIAL STUD (230V ONLY)	ST-24173	1	1
10. FUSE HOLDER	FU-3772	1	1
FUSE, 15 AMP	FU-3775	2	2
11. GLASS, END, CLEAR	GL-25963	2	2
GASKET, END GLASS	GS-22547	2	2
12. GLASS, FRONT	GL-24165	2	2
HANDLE, GLASS, EXTRUSION	HD-26589	1	1
13. HEATING CABLE, 277.5' (84572mm)	CB-3045	X	X
14. HINGE ASSEMBLY, LEFT-HAND	HG-26523	1	1
HINGE ASSEMBLY, RIGHT-HAND	HG-26522	1	1
HINGE ASSEMBLY, MIDDLE	HG-26722	1	1
15. INDICATOR LIGHT, WHITE	LI-3027	3	3
INDICATOR LIGHT, WHITE, 230V	LI-3951	3	3
16. INSULATION	IN-22364	3	3
INSULATION	IN-2203	1	1
17. LEGS, 6" (152mm)	LG-22341	5	-
18. PAN DIVIDERS SEE PAGES 6 & 7			
19. PANEL, FRONT, UPPER	1004274	1	1
PANEL, FRONT, LOWER	1004277	1	1
20. PLUG	PG-3267	1	1
21. SWITCH, TOGGLE	SW-33896	3	3
22. TERMINAL BLOCK, MODULAR	BK-25432	1	-
23. THERMOSTAT	TT-3498	3	3
THERMOSTAT KNOB	KN-3473	3	3
THERMOSTAT, BEZEL	TT-3713	3	3
24. TRACK, DOOR, BOTTOM	TK-25793	1	1
TRACK, DOOR, TOP	TK-25791	1	1
25. STRUTS, GAS	SU-24830	3	3

EC2 SERIES HOT DISPLAY CASE



Inside the top - lights

LP-3384 (230V)
 LP-33592 (120/208-240V)




Bulb Receptacles

RP-3955 (230V)
 RP-3952 (120/208-240V)

6 LAMPS TYP. {NOTE: LP-33712 FOR
(LP-33592) PUBUX USE ONLY}
100 WATTS, 130V EACH

NOTE #1: ALL NUMBERS IN () = ALTO-SHAAM PART NO'S
NOTE #2: SEE DRW. #A-8166 FOR WIRE ASSEMBLIES



120/208V	120/240V
50/60Hz	50/60Hz
2400W	3350W
12.0A	14.0A


WIRING DIAGRAM


MODELS: EC2,ED2,TY2-48 & /P 120/208-240V

ALTO-SHAAM®

MENOMONEE FALLS, WISC. 53052-450

BY: AHL	SCALE: NONE	DWG: 7661
APP'D: DDF	DATE: 06/11/03	







WIRING DIAGRAM

MODELS: EC2, ED2, TY2-96, P, PL, PR 120/208-240V

ALTO-SHAAM
MENOMONEE FALLS, WISC. 53052-450

BY: DDF SCALE: NONE DWG: 7682
APP'D: PED DATE: 01/07/04 A-7682





TRANSPORTATION DAMAGE and CLAIMS



All Alto-Shaam equipment is sold F.O.B. shipping point, and when accepted by the carrier, such shipments become the property of the consignee.

Should damage occur in shipment, it is a matter between the carrier and the consignee. In such cases, the carrier is assumed to be responsible for the safe delivery of the merchandise, unless negligence can be established on the part of the shipper.

1. Make an immediate inspection while the equipment is still in the truck or immediately after it is moved to the receiving area. Do not wait until after the material is moved to a storage area.
2. Do not sign a delivery receipt or a freight bill until you have made a proper count and inspection of all merchandise received.
3. Note all damage to packages directly on the carrier's delivery receipt.
4. Make certain the driver signs this receipt. If he refuses to sign, make a notation of this refusal on the receipt.
5. If the driver refuses to allow inspection, write the following on the delivery receipt:

*Driver refuses to allow inspection
of containers for visible damage.*

6. Telephone the carrier's office immediately upon finding damage and request an inspection. Mail a written confirmation of the time, date, and the person called.
7. Save any packages and packing material for further inspection by the carrier.
8. Promptly file a written claim with the carrier and attach copies of all supporting paperwork.

We will continue our policy of assisting our customers in collecting claims which have been properly filed and actively pursued. We cannot, however, file any damage claims for you, assume the responsibility of any claims, nor accept deductions in payment for such claims.

ALTO SHAAM[®] LIMITED WARRANTY

Alto-Shaam, Inc. warrants to the original purchaser that any original part that is found to be defective in material or workmanship will, at our option, subject to provisions hereinafter stated, be replaced with a new or rebuilt part.

The labor warranty remains in effect one (1) year from installation or fifteen (15) months from the shipping date, whichever occurs first.

The parts warranty remains in effect one (1) year from installation or fifteen (15) months from the shipping date, whichever occurs first.

Exceptions to the one year part warranty period are as listed:

- A. Halo Heat cook/hold ovens include a five (5) year parts warranty on the heating element. Labor will be covered under the terms of the standard warranty period of one (1) year or fifteen (15) months.
- B. Alto-Shaam Quickchillers include a five (5) year parts warranty on the refrigeration compressor. Labor will be covered under the terms of the standard warranty period of one (1) year or fifteen (15) months.

This warranty does not apply to:

1. Calibration.
2. Replacement of light bulbs and/or the replacement of display case glass due to damage of any kind.
3. Equipment damage caused by accident, shipping, improper installation or alteration.
4. Equipment used under conditions of abuse, misuse, carelessness or abnormal conditions.
5. Any losses or damage resulting from malfunction, including loss of product or consequential or incidental damages of any kind.
6. Equipment modified in any manner from original model, substitution of parts other than factory authorized parts, removal of any parts including legs, or addition of any parts.

This warranty is exclusive and is in lieu of all other warranties, expressed or implied, including the implied warranties of merchantability and fitness for purpose. In no event shall the Company be liable for loss of use, loss of revenue, or loss of product or profit, or for indirect or consequential damages. This warranty is in lieu of all other warranties expressed or implied and Alto-Shaam, Inc. neither assumes or authorizes any persons to assume for it any other obligation or liability in connection with Alto-Shaam equipment.

ALTO-SHAAM, INC.

Warranty effective January 1, 2000

RECORD THE MODEL AND SERIAL NUMBER OF THE UNIT FOR EASY REFERENCE.
ALWAYS REFER TO BOTH MODEL AND SERIAL NUMBER IN ANY CONTACT WITH ALTO-SHAAM REGARDING THE UNIT.

Model Number: _____

Date Installed: _____

Voltage: _____

Purchased From: _____

Serial Number: _____

W164 N9221 Water Street • P.O. Box 450 • Menomonee Falls, Wisconsin 53052-0450 • U.S.A.

PHONE: 262.251.3800

FAX: 262.251.7067 • 800.329.8744 U.S.A./CANADA

WEBSITE:

800.558.8744 U.S.A./CANADA

262.251.1907 INTERNATIONAL

WWW.alto-shaam.com